

DECK SUPPORT PLATE ATTACHMENT

FIRST:
PRIOR TO LAYING DOWN DECK,
ORIENTATE DECK SUPPORT PLATE AS NECESSARY
BETWEEN WALL AND FRAMING SO AS TO SUPPORT
DECK MATERIAL (ROOF DECK, BARGRATING, FLOOR
PLATE) IN ITS WEAK DIRECTION.

SECOND:
SCREW DECK SUPPORT PLATE TO
FRAMING WITH (4) TRAXX #5 X 1 1/4" LG
SCREWS AS SHOWN.

NOTE: SUPPORT DECK MATERIAL AS SHOWN
AT EVERY FRAMING INTERSECTION, OR
WHERE A "SAG" MAY OCCUR WHERE THE DECK
MATERIAL GRAIN IS PARALLEL TO THE WALL, ETC.

(4) TRAXX #5 X 1 1/4" LG SCREWS
PER DECK SUPPORT PLATE AS SHOWN

DECK SUPPORT PLATE
(11 GA. X 12" X 18")

GAP

MEZZANINE FRAMING

DETAIL 19A

DECK SUPPORT PLATE DETAIL

